





The most advanced Australian made aluminium fencing gate system.

31 Old Maryborough Rd, Pialba Qld 4655 Phone: (07) 4124 4985

wwwadmin@frankshomedecor.com.au

WWW.FRANKSHOMEDECOR.COM.AU





Simple and neat design, the Ezi-Ali 75mm aluminium blade slots into the TENSION-LOC slotted frame.

The 75mm blade provides a 2.4m span without the need for a support rail. This provides a clean and aesthetically pleasing screen.

STYLE & QUALITY

- Super strength powder coated aluminium.Patented spring loaded frame holds slats without rivets, screws, nails or welding.
- Blades do not warp, crack or splinter.
- Low maintenance.
- Non-weld assembly for easy installation.Powder coated & finished in Australia.
- 7 years warranty







STEP 1: SELECT YOUR COLOUR



WOOD GRAIN

Ezi-Ali aluminium screening is available in 11 Eurowoop™ timber finish colours and 12 textured powder coat solid finishes.

SOLID COLOUR

Ezi-Ali aluminium screening is also available in a number of other powder coat finishes through special order.

ASK OUR DESIGN CENTRE STAFF FOR MORE DETAILS!

WESTERN RED CEDAR	SLATE GREY
JARRAH	MONUMENT
MERBAU	JASPER
KWILLA	SURFMIST
SPOTTED GUM	PRIMROSE
BLACK OAK	DUNE
SMOKED OAK	SILVER
	BLACK
LIGHT OAK	DEEP OCEAN
BEACH OAK	PAPERBARK
BLUE OAK	IRONSTONE
GOLDEN OAK	PEARL WHITE

The colours shown in this catalogue are as close to the actual colours as the printing process allows and might vary from the actual EurowoopTM images or powder coated colour. MPG GROUP recommends using colour samples which are available upon request.

STEP 2: SELECT YOUR BLADE SPACING

There are 2 spacing options for your Ezi-Ali screen, fence or gate:

- 9mm spacing provides extra privacy where required.
- 20mm spacing allows for better air flow and ventilation.

Once you have selected your slat spacing, refer to the Design Guide to confirm how many 75mm Ezi-Ali blades you will require for your screen height.

9mm SPACING		20mm SPACING	
Screen Height	Slats Required	Screen Height	Slats Required
848mm	10	969mm	10
932mm	H	1064mm	П
1016mm	12	1159mm	12
1100mm	13	1254mm	13
II84mm	14	1349mm	14
1268mm	15	1444mm	15
1352mm	16	1539mm	16
1436mm	17	1634mm	17
1520mm	18	1729mm	18
1604mm	19	1824mm	19
1688mm	20	1919mm	20
1772mm	21	2014mm	21
1856mm	22	2109mm	22
1940mm	23	2204mm	23
2024mm	24	2299mm	24
2108mm	25	2394mm	25
2192mm	26	2489mm	26
2276mm	27	2584mm	27
2360mm	28	2679mm	28

STEP 3: SELECT YOUR BASIC INSTALLATION

- 1- Insert the blades (B) one at a time into the slotted frame (A1).
 Using a soft head mallet, tap the blades until they are fully engaged in the slotted frame.
- 2- Engage the blades with the second slotted frame (A2). Use the soft head mallet again, but this time tap the slotted frame (A2) until all blades are fully engaged.
- 3- Once your screen is complete, use either a U-channel, F-Section or a 25mm angle to attach your screen to posts, pillar or any other structure.





